

# **FORD BRONCO (2021+) ROOF MOUNTING KIT**















# WHAT'S INCLUDED

- 2x Roof Mounting Brackets
- Fixtures

#### **TOOLS REQUIRED**

- Pry Tool
- 10mm Socket or Wrench
- Torx bit (Included with lamp)

#### **COMPATIBLE WITH LAMPS:**

- Linear-42 / Linear-42 Elite
- LR-24 Elite / LR-24 Elite+



### **PRE-INSTALLATION CHECKS**

Ensure all vehicle systems are fully operational prior to install, and directly afterwards.

Ensure battery is disconnected.

# MOUNTING BRACKET INSTALLATION



#### STEP 1

Using a suitable pry tool remove the painted accessory caps.



#### STEP 2

Using a 10mm socket or wrench, remove the two M6 nuts (save for re-installation) that hold the accessory cap bracket to the roof and discard of the caps and brackets.





# STEP 3

Install the Triple-R Lights roof bracket to the roof using the OE M6 nuts removed previously.



# STEP 4

Snug down OE hardware using a 10mm wrench or socket (do not torque yet).



### STEP 5

With help of another install the light bar using the supplied hardware



# STEP 6

Adjust light to desired location and tighten all hardware (see ford dealer for torque specs of OE hardware).

#### STEP 7

Run wiring to desired switch. It is recommended to use the available corresponding Triple-R wiring kit for your product (please refer to the wiring kit product page for further wiring instructions).

